

35487-MP

Heat or Cool Thermostat

Enclosed, Multi purpose, compact digital thermostat with isolated relay output and 3digit 0.25" LCD display.

Features: Programmable set Point, Cool or Heat control, Hysteresis, Delay and High Temp. Alarm.

Control Temperature Range: -50 to +110 deg. "C"

Power: 6-30VDC

Current: ~80mA Relay open/~120mA Relay energized @ 12VDC

Refresh rate: 0.5sec.

Resolution: 0.1 deg . from -9.99 to +99.9

1.0deg. for above 100deg. "C"

Accuracy: Measurement : 0.1deg.

Control: 0.1deg.

Relay: SPST-NO 10A/14VDC; 10A/125VAC

Sensor: 10K Ohm NTC Waterproof Stainless probe (.5m leads)

Module Temp. Range: -10 to 60deg. "C"; 5-95% humidity

Terminal Strip for Power & Relay contacts.

Cutout: 75mm X 39.5mm

W: 3-1/8in. **H:** 1-11/16in. **D:** 1-1/16in. **WT:** .1

Buttons: "▲" Up/Increase

"▼" Down/Decrease

"⊙" SET

"⏻" STOP Normal Mode

Enable/Disable in Setting Mode



Display: UPPER Normal Mode: Probe Temp

Quick Set Mode: Hysteresis

Full Set Mode: Hi Alarm/Restart Delay/
Correction Values

"OUT" Relay Contacts Closed/Flashing if Manual Off

"H" Heat Mode "C" Cooling Mode

"W" Working Mode (Normal Mode)

"SET" Set/Adjust Mode

"h" Restart Delay (OPH) Hold Time enabled

---- Selected Function (Hi-Temp Alarm (ALA)/Restart
Delay (OPH) are Disabled)

SEE PG. 2

Operation:

1: Place Controller in desired location along with the probe

2: Connect Load to Controller Relay Contacts (Be sure Load power is off)

3: Connect 6-30VDC Power Supply to Controller

Display will show: Upper Line: Temperature at Probe tip

Lower Line: Present Mode ("H" or "C"), and Set Temperature

"h" if Restart Delay is Enabled

"W" Working (Normal Operating Mode)

Information including Drawings, Schematics, Links and Code (Software) Supplied or Referenced in this Document is supplied by MPJA inc. as a service to our customers and accuracy or usefulness is not guaranteed nor is it an Endorsement of any particular part, supplier or manufacturer. Use of information and suitability for any application is at users own discretion and user assumes all risk.

Information Subject to Change Without Notice
All rights are retained by the respective Owners/Author(s)



MARLIN P. JONES & ASSOC., INC.

P.O. Box 530400 Lake Park, FL 33403

800-652-6733 FAX 561-844-8764

WWW.MPJA.COM

DURING ANY SETTING: IF NO BUTTON(S) PUSHED FOR ~7SECONDS UNIT REVERTS TO WORKING MODE

Quick Set:

NOTE: If no adjustments are made within ~7 seconds, unit will revert to normal operation

1: Press SET (⊗) Button Momentarily

The Lower display will flash “H” or “C”

1.1: Press the ▲ or ▼ Buttons to alternate Heat or Cool Mode

2: Press ⊗ Button momentarily

The Lower display will flash the present set temperature

2.1: Press the ▲ or ▼ Buttons to adjust to the desired temperature value (0.1deg increments)

3: Press ⊗ Button momentarily

The Upper display will flash the present **Hysteresis** value

NOTE: Always put a value here! Otherwise the Relay may rapidly chatter

3.1: Press the ▲ or ▼ Buttons to adjust to the desired Hysteresis value (0.1deg increments)

Cool: Set temperature + Hysteresis value

Heat: Set temperature - Hysteresis value

Full Setting:

1: Setting the **High Temperature Alarm** Value (110° C Max)

1.1: Press SET (⊗) Button AND Hold for >5 seconds

The Upper display will flash a “----” or a Value (---- Means Alarm is Disabled SEE Below)

The Lower display will show “SET” & “ALA”

If ---- Shows: Press “STOP” (⏻) Display will show a value

1.2: Press the ▲ or ▼ Buttons to adjust to the desired High Temp. Alarm Value (1deg increments)

1.3: To Disable/Enable High Temperature Alarm Function At a later Time

Press SET (⊗) Button AND Hold for >5 seconds

The Upper display will flash a “----” or a Value (---- Means Alarm is Presently Disabled)

The Lower display will show “SET” & “ALA”

Press “STOP” (⏻) Button (Alternate Pressing will alternate Enable/Disable)

NOTE: If the High Temperature limit is exceeded

Relay will Open, Display will Flash, Buzzer will sound

To Reset press Any Button

2: Setting the **Restart Delay (OPH)** (Prevents fast cycling 0-9999 minutes)

NOTE: Timer Starts when Relay Contacts Open

2.1: Press SET (⊗) Button AND Hold for >5 seconds

(The Upper display will flash a “----” or a Value)

(The Lower display will show “SET” & “ALPHA”)

2.2 Press ⊗ Button again Momentarily

The Upper display will flash a “----” or a Value (---- Means Restart Delay is Disabled)

The Lower display will show “SET” & “OPH”

2.3: Press the ▲ or ▼ Buttons to adjust to the desired delay Value (1 minute increments)

3: Setting the **Correction Factor** (Accuracy drift, aging) (+-10° C)

NOTE: This Function is not normally used adds/subtracts from actual probe temperature

3.1: Press SET (⊗) Button AND Hold for >5 seconds

The display will be as above

3.2 Press SET (⊗) Button Momentarily Twice

The Upper display will flash a “----” or a Value

The Lower display will show “SET” & “OFC”

3.3: Press the ▲ or ▼ Buttons to adjust to the desired delay Value (0.1deg increments)

4: RESET:

4.1 Press AND Hold “SET” And “STOP” (⏻) Buttons