



31390 MI

MPJA Inc

8380 Resource Drive

West Palm Beach, FL 33404

www.mpja.com



Step 1

Trim
Trim

Trim plastic horn from servo with a knife (carefully) to fit in base (A).

Step 2

Use screws to mount horn to base (A).

Step 3

Slide parts (B) and (C) over mounting tabs of a servo, do not use screws at this time, you will need wiggle room later.

Step 4

Trim
Trim

Trim plastic horn from servo with a knife (carefully) to fit in (C) and insert screw.

Step 5

Mount second servo to (D) note orientation in picture.

Step 6

Slide (D) into (B) and (C) now is when you need the wiggle room.

Step 7

screw hole
screw hole

Insert screws to tighten (B) and (C)

Step 8

Insert screw through bottom to tighten servo to base.