33038-MI

Scrolling LED Name Tag

Programmable scrolling LED name tag ideal for restaurants, trade shows, reunions. Put names, promotions, web addresses, anything you want. Internal rechargeable Li-ion battery for repeated use. Input your text & graphics by USB from your PC. Files can be Saved for future use.

Matrix: 11 X 44 LEDs

Memory: 8 messages with up to 190 characters/message. Up to 6 characters displayed at a time. (Language/case Dependent)

PIN

CLASP

MAGNET

CLASP

■USBJACK

PUSHBUTTON

SWITCH

POWER

SWITCH

Run Time: >15hr. @ 25% Brightness/>8hr. @100%

Charge Time: <3hr.

Programming/Charge Port: USB Mini B

L: 3.7" **W:** 1.18" **T:** 0.4" WT: .06

SETUP & PROGRAMMING SEE Pages 2 & 3

1: Load Supplied CD into your computer

Open to view Files

2: Select "Mini LED. exe"

File loads & opens to Main Screen Should automatically default to English Select different language as needed

3: Attach Supplied USB Cable to your computer port

Connect USB cable to Mini B on Name Tag 4: Tag will activate (regardless of ON/OFF switch)

Will show factory default info. or last active message(s)

5: Select the message line you want to write into

Select EDIT (FORMAT) Menu

Select TXT/RTF/Image/GIF

Double Click in Text Bar.

Text screen will open

Type or load information

Click OK (Returns to Main Screen)

6: Select features such Speed, Dwell etc. by clicking on Icons next to Message Bar

7: When all choices are made;

Select "SEND" on "Tool" Bar to download to Tag You may select "FILE" on "Menu" bar to "Save", "Save As" etc. to keep your file for future use or to down load to another Tag

OPERATION

1: Turn on Tag

Battery Status will appear for Approxmately. 5sec.

Tag will then begin to display programmed information

2: Message Selection

Momentararry press pushbutton on back.

Each press will scroll through the Messages programmed in

memory from 1st. enabled message (see Setup) until last

When Message to be displayed appears, wait >5sec. to lock in selection

After Last message, next button press will select Scroll of all messages

3:Brightness Adjustment

Press & Hold the pushbutton switch on back for >5sec.

% of Brightness will appear. Continue to hold Button until desired Level is dispayed

Information and Software obtained from or supplied by Mpja.com or Marlin P. Jones and Associates inc. is supplied as a service to our customers and accuracy or usefulness is not guaranteed nor is it definitive of any particular part or manufacturer. Use of information and suitability for any application is at users own discretion and user assumes all risk.


All rights are retained by the Author




MARLIN P. JONES & ASSOC., INC.


P.O. Box 530400 Lake Park, FI 33403 800-652-6733 FAX 561-844-8764 WWW.MP.JA.COM

33038-MI Scrolling LED Name Tag







MAIN SCREEN



33038-MI Scrolling LED Name Tag





Information and Software obtained from or supplied by Mpja.com or Marlin P. Jones and Associates inc. is supplied as a service to our customers and accuracy or usefulness is not guaranteed nor is it definitive of any particular part or manufacturer. Use of information and suitability for any application is at users own discretion and user assumes all risk.

All rights are retained by the Author



MARLIN P. JONES & ASSOC., INC.

P.O. Box 530400 Lake Park, FI 33403 800-652-6733 FAX 561-844-8764 WWW.MPJA.COM