

17417-PS
FUGI/XEROX
+24VDC @ 4.5A

INPUT CONN.	OUTPUT CONN.
1: GROUND	1: + 24VDC OUT
2: KEY No Pin	2: - RETURN (GROUNDED)
3: NEUTRAL	3: NOT CONNECTED
4: LINE	4: + 24VDC OUT
	5: - RETURN (GROUNDED)
Note: Output Pin 1 connected to Pin 4 Output Pin 2 connected to Pin 5	