



- 1: For Isolation Relay Power: Remove jumper from P2
 Supply an external +5V to P2 pin 3 (Rly-Vcc) & external supply Ground to P2 pin 1
 +5V & Gnd. from microcontroller board must still connect to P1-10 (Vcc) & 1 (Gnd)
- 2: For Single Supply Operation (from microcontroller) leave P-2 Jumpers

www.mpja.com		
Title		
8 Channel Relay Board		
Size	Document Number	Rev.
	33329-MP	
Date	Sheet	

Information obtained from or supplied by Mpja.com or Marlin P. Jones and Associates inc. is supplied as a service to our customers and accuracy is not guaranteed nor is it definitive of any particular part or manufacturer. Use of information and suitability for any application is at users own discretion and user assumes all risk.