



NOTE
 12V POWERED BOARD
 DO NOT CONNECT TO OTHER
 VOLTAGE

- 1: Each Relay can be Set for Active "LOW" Input Activation OR Active "High" Input Activation
- 2: For Active "Low" Activation: Place Jumper on Header Between "COM" & "LOW" Pins of Corresponding Relay
- 3: For Active "HIGH" Activation: Place Jumper on Header Between "COM" & "HIGH" Pins of Corresponding Relay

Information obtained from or supplied by Mpja.com or Marlin P. Jones and Associates inc. is supplied as a service to our customers and accuracy is not guaranteed nor is it definitive of any particular part or manufacturer. Use of information and suitability for any application is at users own discretion and user assumes all risk.

www.mpja.com		
Title 12V 4 Channel Relay Board		
Size	Document Number 35787-MP	Rev.
Date 5/19	Sheet	