## INSTALLATION INSTRUCTION


for

P/N.: M66201-M2

Power Supply Model PSM66-201

REV:A

- The power supply shall be operated at an ambient temperature of 0°C to 50°C maximum.
- The power supply is a built-in component. During installation into a certain equipment, the relevant requirement EN 60950 shall be maintained.
- 3. The creepage distances, clearance and thickness of insulation between primary and ground as well as primary and secondary circuits shall comply with the current requirement of EN 60950.
- Leakage current not over 3.5mA.
- This switching power supply is not provided AC power cord. Make sure that mains outlet is installed near the equipment and is 5. easily accessible.
- The power supply shall be installed according to the specification. 6. The current of each load and total output power of all loads shall not be over the specified values:



Pin Assignr	nents
Connectors	PSM66-201

CN1-1 CN1-2	Line Neutral		
CN2-1	+5V	CN2-7	RTN.
CN2-2	+5V	CN2-8	N.C.
CN2-3	+5V	CN2-9	RTN.
CN2-4	+5V	CN2-10	RTN.
CN2-5	N.C.	CN2-11	N.C.
CN2-6	RTN.	CN2-12	+12V