



33596-MI Sound Level Indicator

This is a level indicator Not a calibrated VU meter. LEDs light in pairs.

1: OPERATION

When Power Applied:

Some Lines will light to indicate the present Sensitivity setting. With line

1 lit being Most sensitive and lines 1 thru 10 all lit being least sensitive

After ~5seconds Module will revert to Normal working mode

2: SETTING SENSITIVITY Also Used to Match 2 or more Modules

With Power Applied: Press and hold the Switch for >5seconds. Release switch

Line #12 will lite to indicate Setting Mode and present Sensitivity is shown.


To adjust sensitivity; momentarily press switch.

Each press will sequentially increase lines lit from 1to10 (Decrease sensitivity)

until lines 1-10 are all lit (Least sensitive), Next press will return to Line 1 lit (Most sensitive)

Press and Hold Switch until Line 13 Blinks indicating storage of setting.

Release Switch and module will return to normal operation



33596-MI Sound Level Indicator

This is a level indicator Not a calibrated VU meter. LEDs light in pairs.

1: OPERATION

When Power Applied:

Some Lines will light to indicate the present Sensitivity setting. With line

1 lit being Most sensitive and lines 1 thru 10 all lit being least sensitive

After ~5seconds Module will revert to Normal working mode

2: SETTING SENSITIVITY Also Used to Match 2 or more Modules

With Power Applied: Press and hold the Switch for >5seconds. Release switch

Line #12 will lite to indicate Setting Mode and present Sensitivity is shown.


To adjust sensitivity; momentarily press switch.

Each press will sequentially increase lines lit from 1to10 (Decrease sensitivity)

until lines 1-10 are all lit (Least sensitive), Next press will return to Line 1 lit (Most sensitive)

Press and Hold Switch until Line 13 Blinks indicating storage of setting.

Release Switch and module will return to normal operation



33596-MI Sound Level Indicator

This is a level indicator Not a calibrated VU meter. LEDs light in pairs.

1: OPERATION

When Power Applied:

Some Lines will light to indicate the present Sensitivity setting. With line

1 lit being Most sensitive and lines 1 thru 10 all lit being least sensitive

After ~5seconds Module will revert to Normal working mode

2: SETTING SENSITIVITY Also Used to Match 2 or more Modules

With Power Applied: Press and hold the Switch for >5seconds. Release switch

Line #12 will lite to indicate Setting Mode and present Sensitivity is shown.

To adjust sensitivity; momentarily press switch.

Each press will sequentially increase lines lit from 1to10 (Decrease sensitivity)

until lines 1-10 are all lit (Least sensitive), Next press will return to Line 1 lit (Most sensitive)

Press and Hold Switch until Line 13 Blinks indicating storage of setting.

Release Switch and module will return to normal operation

