

# 35490MI

## DIGITAL CLOCK

Default Display Order: 1 year, 2 date, 3 time, 4 temperature


TIME & DATE SET



Normal Display




1Hz flashing





Change the LED display:



DS1302 clock circuit is not working properly:

Power on



DS18B20 clock circuit is not working properly:

Power on



Functional specifications:

1、Hourly Chime:

Enable Hourly Chime function, 8:00 to 22:00, the buzzer will Beep every hour.

2、Clock Alarm:

Enable the alarm function , the buzzer will ring at the specified time, press any button to stop the ringing.

3、Temperature alarm:

Lower than the specified minimum temperature or higher than the specified maximum temperature, the buzzer will sound and lights flashing.